



May 26, 1993

ONR CONTRACT N00014-93-C-0051
 PROGRESS REPORT NO. 2 FOR APRIL 16 - MAY 15, 1993
 SHIPMENT NUMBER NRD0001AB

D
EI
JL
S

Substantial experimental progress has been made, in the second month of the project, in setting up and testing for producing chaotic behavior with a CO₂ laser. The project goal is to synchronize a chaos in CO₂ and other lasers, and thereby increase the power in ensembles of coupled laser sources.

Weekly Coordination Meetings of the project team have been held. These meetings have been well attended by the project members. Significant technical discussions regarding approaches to the data and theoretical analysis have occurred. The successful experimental results described later have provided insight regarding theoretical considerations. Analysis of the chaotic regime, in detail, is awaiting the next experiments, with additional care to be taken in recording data for subsequent analysis. A second prototype is in the initial stages of assembly. Initial checkout of components indicates a working system should be achieved.

TECHNICAL EXPERIMENTAL PROGRESS:

Last month's report described the technical aspects of the project and the progress made towards a laboratory setup to carry out the experimental investigation of nonlinear dynamics of CO₂ lasers. Since then, new results have been obtained by a simple new technique to induce chaos in CO₂ lasers. In this technique, acoustically modulated feedback of the laser light is used. This new technique, and the results obtained, are described in the following sections.

1. Laboratory Setup

The laboratory experimental setup is shown in Figure 1. The CO₂ laser used consists of a gas-filled glass tube, a plane grating and a ZnSe output coupler. The length of the laser cavity is 2.5 m and the maximum output power is about 5 W. The output beam of 10.6 micron wavelength from the CO₂ laser is directed normal to a ceramic surface attached to a diaphragm of a radio speaker. The radio speaker is driven by a frequency generator capable of driving the speaker in the frequency range of 10 Hz to 100 kHz. The laser setup is on an optical table that is mounted on air legs to minimize mechanical vibrations. The laser signal at the grating is detected by a HgCdTe high frequency detector. The output signal of the detector, after being amplified, is sent to a spectrum analyzer. The signal is also sent to a scope in XY mode to record the phase portrait. To obtain the phase portrait, the signal is divided into two parts, and a fixed delay is introduced between the two signals.

2. Results

Experimental results are shown in Figures 2 and 3. In these Figures phase portraits, (Intensity(t + τ)), are displayed on the right and the corresponding frequency spectra are on the left, for various modulation frequencies. Initially a stable laser output is obtained without any feedback or outside modulation. To investigate the influence of acoustically modulated feedback, oscillations are turned on, in the form of a sine wave, attached to an audio speaker, at a frequency of 51.4 kHz (Fig 2a). The frequency spectrum in Figure 2b shows a second harmonic at 102.2 kHz in addition to the peak at the modulation frequency (51.4 kHz), which indicates that acoustically modulated optical feedback produces periodic oscillations in laser output not seen from a stationary reflecting surface.

TEL: (817) 565-4990

TEL: (512) 334-8641

FAX: (817) 565-3802

1921 Edwards St., Suite 9, {Do not use for mail} Denton, Texas

93

93-123



Approved for public release
 Distribution Unlimited

ONR CONTRACT N00014-93-C-0051
 PROGRESS REPORT NO. 2 FOR APRIL 16 - MAY 15, 1993 - CONT'D
 SHIPMENT NUMBER NRD0001AB

Various frequencies were used to investigate the effect of modulation frequency on the induced and the induced instabilities in the laser output. These effects are illustrated in Figures 2c and 3. As the frequency of modulation is varied, (in this case decreased) the laser output becomes more and more complex. This is shown in Figure 2c where five harmonics are observed in addition to the modulation frequency of 1 kHz. The related phase portrait changes are shown in Figures 2b and 2d.

As the modulation frequency approaches about 7 kHz, the frequency spectrum of the laser output as shown in Figure 3a, indicating the presence of a higher period orbit accompanied with subharmonics. As the modulation frequency is further decreased to 375 Hz, the signal intensity suddenly shows large fluctuations and the frequency spectrum (Figure 3c) becomes broadband with about 30 db rise in the floor level. This strongly indicates that the system is driven into a chaotic regime. The corresponding phase portrait (Fig. 3d) at this modulation frequency of 375 Hz.

SUMMARY:

- * A new technique has been developed to create instabilities and chaos in CO₂ gas laser.
- * This new technique involves acoustically modulated feedback of the laser light.
- * A complicated sequence of interlocking periodic and chaotic regimes in the frequency spectrum of 1 kHz to 100 Hz has been observed and recorded.
- * Preparations are moving forward to control some of these chaotic regimes.
- * A second CO₂ laser is being assembled.

END

DTIC QUALITY INSPECTED 2

St-A per telecon, Dr. Pilloff, ONR/
 Code 1112LO, Arl., VA 22217

6-3-93 JK

Accession For	
NTIS	CRA&I
DTIC	TAB
Unannounced	
Justification	
By	
Distribution /	
Availability Code	
Dist	Avail and/or Special
A1	






Figure 1: Experimental set up: 1. grating 2. CO₂ laser tube 3. output mirror 4. ceram 5. radio speaker 6. frequency generator 7. LN₂ cooled HgCdTe detector 8. oscilloscope 9. delay line 10. spectrum analyzer 11. oscilloscope



(a)



(b)



(c)




(d)


Figure 2: Frequency Spectra (a) and (c) with corresponding Phase Portraits (b) and (d)




(a)



(b)



(c)



(d)

Figure 3: Frequency Spectra (a) and (c) with corresponding Phase Portraits (b) and (d)